














Quick Start

KRUPS
NESCAFÉ
Dolce
Gusto

1 							
2 							
3 							
4 							
5 		EN To STOP preparation earlier, press any button. DE Beliebige Taste drücken, um die Zubereitung vorzeitig zu beenden. FR Pour arrêter la préparation à tout moment, appuyez sur n'importe quelle touche. ES Para parar la preparación antes, pulse cualquier botón. PT Para interromper a extração da bebida, prima qualquer botão. IT Per fermare la preparazione prima, premi un qualsiasi pulsante.				NL Druk op een willekeurige knop om de bereiding eerder te stoppen. GR Για να ΣΤΑΜΑΤΗΣΕΤΕ την παρασκευή του ροφήματος νωρίτερα πατήστε οποιοδήποτε κουμπί.	RU Для остановки процесса приготовления, нажмите на любую кнопку. UKR Щоб зупинити приготування раніше, натисніть будь яку кнопку. KZ Сусынның әзірлiн ертерек аяқтау үшiн кез келген батырманы басы.




EN Troubleshooting
DE Störungsbehebung
FR Dépannage
ES Resolución de problemas

PT Resolução de problemas
IT Risoluzione dei problemi
NL Storingen oplossen
GR Αντιμετώπιση προβλημάτων

RU Устранение неисправностей
UKR Усунення несправностей
KZ Тазарту

KRUPS NESCAFÉ
Dolce Gusto



NESCAFÉ DOLCE GUSTO

www.dolce-gusto.com

UK 0800 707 60 66
CH 0800 86 00 85
DE 0800 365 23 48
AT 0800 365 23 48
RU 495 775 24 28

FR 0800 97 07 80
ES 902 102 706
PT 808 200 153
IT 800 365 234
UKR 0 800 50 30 10

NL 0800 365 23 48
LU 8002 3183
BE 0800 93 217
GR 800 11 68068
KZ 8-800-080-2680

NC00028165-01